



# R SERIES

## RELAY CONTROL PANEL




## APPLICATION OVERVIEW

The R Series Panels are stand-alone relay panels that serve as the primary point of connection in the 2-Wire NexLight Lighting Control System. Utilizing the CRC1301, the R Series panels provide the same Graphic User Interface as the larger capacity CRC1201. Networking multiple (up to 250) standard panels (R Series and/or D Series) is easily done through a standard Ethernet (CAT5E or greater) Local Area Network. This networking approach allows for a truly segmented network design, while retaining the advantage of leveraging the reliability and simplicity of the NexLight 2-Wire Data Bus.

## APPLICATION HIGHLIGHTS

- Networkable via Ethernet.
- Programming, Monitoring and Remote Override available through Graphic User Interface (GUI).
- Utilizes the CRC7000 Mechanically Latching Relay backed by NexLight's 20-Year Relay Warranty.

## TYPICAL RISER



## PANEL SCHEDULE

Information supplied by building IT Department  
Record the control circuit wired to the terminal block

Record the Lighting Load Description  
Record the source circuit breaker

PANEL NAME:		IP ADDRESS:					
MOUNTING LOCATION:		SUBNET MASK:					
TRANSFORMER FEED:		DEFAULT GATEWAY:					
PANEL TYPE: NXL-R32s		PANEL DIMENSIONS:		30.00" H x 24.00" W x 6.00" D			
LEFT SIDE				RIGHT SIDE			
LOAD DESCRIPTION	SOURCE	ADDRESS	DEVICE	DEVICE	ADDRESS	SOURCE	LOAD DESCRIPTION
		0-1	CRC7000	CRC7000	0-2		
		0-3	CRC7000	CRC7000	0-4		
		1-1	CRC7000	CRC7000	1-2		
		1-3	CRC7000	CRC7000	1-4		
		2-1	CRC7000	CRC7000	2-2		
		2-3	CRC7000	CRC7000	2-4		
		3-1	CRC7000	CRC7000	3-2		
		3-3	CRC7000	CRC7000	3-4		
		4-1	CRC7000	CRC7000	4-2		

## STEPS TO INSTALLATION

1. Mount the R Series Panel in the desired location.
2. Wire the CRC7000 Relay to the Source and Lighting Load.
  - Record the Source and Lighting Load Description on the part number specific Panel Schedule.
3. Connect Line Voltage to the Control Power Terminal Blocks.
  - Record the circuit breaker designation in the appropriate field at the top of the Panel Schedule.
4. Proceed with wiring the NexLight 2-Wire Data Bus; Reference the Table of Contents for specific applications.